


Page 3



Thrustmaster HOTAS WARTHOG mounting holes



Place your throttle on the left plate and joystick on the right plate and drive 4 Allen screws (M5x16) with 4 (M5) cups to fix it firmly.
Scan QR code to see set up video




SAITEK X-52/PRO mounting holes



Place your SAITEK X52/PRO throttle and joystick on the main plate and drive 4 conical screws (M4x55) with 4 washers(4) and 4 (M4) cups to fix it firmly.
Scan QR code to see set up video.





SAITEK X55 mounting holes



Place your SAITEK X55 throttle on the left plate and joystick on the right plate and drive 4 conical screws (M4x55) with 4 washers (4) and 4 (M4) cups to fix it firmly.
Scan QR code to see set up video.




SAITEK X-65F mounting holes



Place your SAITEK X65F throttle and joystick on the main plate and drive 4 conical screws (M4x55) with 4 washers (4) and 4 (M4) cups to fix it firmly.
Scan QR code to see set up video.



Thrustmaster T.Flight Hotas 4 mounting holes



Place yourThrustmaster T.Flight Hotas 4 throttle on the left plate and joystick on the right plate and drive 4 conical screws (M4x25) with 4 washers (4) and 4 (M4) cups to fix it firmly.
Scan QR code to see set up video.